



ULSZ.E5946 Audible-signal Appliances

[Page Bottom](#)

Audible-signal Appliances

[See General Information for Audible-signal Appliances](#)

COOPER WHEELOCK INC

E5946

273 BRANCHPORT AVE
LONG BRANCH, NJ 07740 USA

Bells, Models 43T-24, -115AC. For use outdoors when employed with Model WBB back box.

Motor bells, Models MB-G6-6, MB-G6-12, MB-G10-12, MB-G6-24, MB-G10-24 followed by suffix R, S, W or X. Suitable for outdoor use with a WBB back box, may be employed with SB or SBL back box, suitable for indoor use only.

Chimes: For private mode only (d), Models CH70, CH90.

Strobe chimes, for private mode only (d), Models CH70-241575W, CH90-24100C followed by any two alphanumeric characters indicating lens lettering and color; Models CH70-24MCW, CH90-24MCW, CH70-24MCWH, CH90-24MCWH followed by any two alphanumeric characters indicating lettering and product color. Intended for indoor use on the wall.

Models CH70-24MCC, CH90-24MCC, CH70-24MCCH, CH90-24MCCH followed by any two alphanumeric characters indicating lettering and product color. Intended for indoor use on the ceiling.

Horn, Model 31T-115. For use outdoors when employed with Model WBB back box. For indoor use when used with accessories AP, BB, FBB, FP, SFP, SP, TP, for indoor use when employed with back box HG2 (list 8) or HG1 (list 9) or SB or SBL back box.

Can be used outdoors when employed with back box Type WHG2 (list 10) or WHG1 (list 11).

Horns, Model MIZ followed by -12, -12S, -24 or -24S, followed by suffix R, W or X. For indoor use only.

Model MIZ followed by -TC12 or -TC24, followed by R or W. For indoor use only.

Models NH-12/24, NH-12/24R, ZNH followed by an alpha or numeric character indicating color. For indoor use.

Sync strobe horn, Model M17 followed by 24, followed by SC, SHW or SLM, followed by any three alpha/numeric characters indicating lens orientation, lens lettering and lens color.

Multi-tone horns, Model MT followed by no suffix or 4, followed by -12/24 or -115, followed by -R, -S, -W or X.

Model AMT followed by no suffix or 4, followed by 12/24, followed by R, S, W or X, may be followed by NYC. Suitable for outdoor use.

Multi-tone horns and strobes, Model MT followed by no suffix or 4, followed by -115, followed by -WH. Model MT followed by no suffix is suitable for outdoor use with Model IOB back box. Model MT followed by suffix 4 is suitable for outdoor use with Model WBB back box or Model WFP flush plate used with a 4" square flush Backbox.

Model MT followed by 12 or 24 for voltage, followed by strobe/candela (1575 = 15cd with 75 on axis, 75 = 75cd), followed by W for wall mount, followed by product lettering (eg-F - fire) and product color (R = red, W = white, S = silver/grey, X = special). Example Model Code: MT-241575W-FR.

Multi-tone horn/multi-candela strobe, Model MT-24MCW followed by any alpha numeric characters indicating enclosure marking and product color.

Multi-tone horn/strobe, Model AMT followed by no suffix or 4, followed by 12 or 24, followed by WH or WM, or 1575W or 75W, followed by any three alpha/numeric characters indicating lens orientation, lens lettering and lens color, may be followed by NYC. Suitable for outdoor use.

Flush mounted units employ, Model FSB-1 back box.

Strobe horn for hearing impaired, Model MT followed by 4 or no suffix, followed by 12 or 24, followed by -HSPW (w/24 prefix only), -IS (w/24 prefix only), -LS, -LSM, -MS (w/ 24 prefix only), -L-LS (w/24 prefix only), followed by SL, SLM or SHPW, followed by any three alpha/numeric characters indicating lens orientation, lens lettering and lens color. Indoor use only, nonsleeping areas.

Model MTWP followed by -24 indicating voltage, followed by 75 indicating candela rating, followed by W for wall mount, followed by product lettering (eg-F - fire) and product color (R = red, W = white, S = silver/grey, X = special). Example Model Code: MTWP-2475W-FR.

Strobe horns for the hearing impaired, Model AMT followed by no suffix or 4, followed by 12 or 24, followed by -HSPW, -IS, -LS, -LSM, -MS followed by any three alpha/numeric characters indicating lens orientation, lens lettering and lens color, may or may not be followed by NYC. For indoor use only.

Model MIZ followed by 12-LS, 12-LSM, 12-MS, 24-HSW, 24-IS, 24-LS, 24-LSM, 24-MS, 24L-HSW, 24L-LS, followed by any three alpha/numeric characters indicating lens orientation, lens lettering and lens color. Indoor use only, nonsleeping area.

Horn/strobes, Models AS-1230, -121575, -241575 followed by any three alpha/numeric characters indicating lens orientation, lettering and color; Models AS-24MC, -241575 followed by W for wall units only, followed by any two alpha/numeric characters indicating lens orientation, lettering and color. For indoor use only. Models ASWP-2475W, -2475C, -24MCCH, -24MCWH followed by any two alphanumeric characters indicating lettering and product color. For indoor/outdoor use when used with the WPBB back box or WFPA flush plate used with either a double gang or a 4" square flush Backbox.

Model AS-24MCC followed by any two alpha/numeric characters indicating lens orientation, lettering and color. For indoor use only.

Models AS-24MCWH, AS-24MCCH followed by any two alphanumeric characters indicating lens orientation, lettering and color. For indoor use only.

Models HS4-24MCW, HS4-241575W, HS4-24150W, HS4-24177W, HS4-24185W, HS4-24177C, HS4-24150C, HS4-24MCWH, HS4-24MCC, HS4-24MCCH. For indoor use only.

Horns, Models AH-12, -24 followed by an alpha or numeric character indicating product color. Indoor/outdoor use.

Model HS-24 followed by an alpha or numeric character indicating product color. For indoor use only.

Horn/strobes, Models NS, NS4 followed by -121575, -1215, -2415, -24110, -241575, -2430, -2475, -24MCW, -24MCC, -24MCCH, followed by any three alpha/numeric characters indicating lens orientation, lettering and color. For indoor use.

Models ZNS followed by -MCC, -MCCH, -MCW, -MCWH followed by any two alpha/numeric character indicating lens lettering and color.

"Slow-Whoop" horn, EW- followed D or E, followed by H1-, followed by R, S, W, WI, WR or X. Model EW-E Series is suitable for outdoor use with Model SBL or WBB back box, Model SB back box is for indoor use only.

"Slow-Whoop" horn/strobe, EW- followed by B, D or E, followed by H1-, followed by A, B, G, R or W, followed by H, M or S, followed by 24, followed by any three alpha/numeric characters indicating lens orientation, lens lettering and lens color. Model EW-F Series is suitable for outdoor use with Model SBL or WBB back box. Model SB back box is for indoor use only.

Audible signal appliance for fire alarm service with signaling appliance for the hearing impaired, Exceder Series, Model HS, followed by R (Red) or W (White), then may be followed by S indicating Silver fascia, followed by (X), where X indicates lens lettering. Intended for indoor use only, mounted on a wall.

Audible signal appliance for fire alarm service with signaling appliance for the hearing impaired, Exceder Series, Model HS-C, followed by R (Red) or W (White), then may be followed by S indicating Silver fascia, followed by (X), where X indicates lens lettering. Intended for indoor use only, mounted on a ceiling.

Audible signal appliance for fire alarm service with signaling appliance for the hearing impaired, Exceder Series, Model HS(X), where X indicates color, then followed by -NR indicating non-resettable.. Intended for indoor use only, mounted on a wall.

Audible signal appliance for fire alarm service with signaling appliance for the hearing impaired, Exceder Series, Model HS(X)C, where X indicates color, then followed by -NR indicating non-resettable. Intended for indoor use only, mounted on a ceiling.

Audible signal appliance for fire alarm service, Exceder Series, Model HN, followed by R (Red) or W (White), then may be followed by S indicating Silver fascia, followed by (X), where X indicates lettering. Intended for indoor use only, mounted on a wall.

Audible signal appliance for fire alarm service, Exceder Series, Model HN-C, followed by R (Red) or W (White), then may be followed by S indicating Silver fascia, followed by (X), where X indicates lettering. Intended for indoor use only, mounted on a ceiling.

Audible signal appliance for fire alarm service, Exceder Series, Model HN(X), where X indicates color, then followed by -NR indicating non-resettable. Intended for indoor use only, mounted on a wall.

Audible signal appliance for fire alarm service, Exceder Series, Model HN(X)C, where X indicates color, then followed by -NR indicating non-resettable. Intended for indoor use only, mounted on a ceiling.

Accessories, Models AP, BB, DBB, DFB, FBB, FP, FSB1, IOB, IOB-KIT, ISP, ISP2, NATP, RP, SB, SBB, SBL, SBL-1, -2, SER, SFP, SHBB, SHMP, SP, SSB-4, TP, UFP, WBB, WFP, WFPA, WP-KIT, WPBB, ZBB.

Accessories, Models DSM-12/24, SM-12/24 followed by R, S, W or X. For use with AS Series horn/strobe. For indoor use only.

Accessory, Model NATP TRIMPLATE.

*a T designates use of terminal block termination.

*b G4, G6, G8, G10 designates bell shell diameters.

*c Color, gray or red.

*d These units must be set at max volume for "Fire Alarm Service, Private Mode per NFPA 72".

Last Updated on 2009-07-13

[Questions?](#)

[Notice of Disclaimer](#)

[Page Top](#)

Copyright © 2009 Underwriters Laboratories Inc.®

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Listed and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Designs and/or Listings (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from Underwriters Laboratories Inc." must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "Copyright ©

2009 Underwriters Laboratories Inc.®

An independent organization working for a safer world with integrity, precision and knowledge.

